正面

魔域触摸蓝牙手柄
产品说明书(PG-9069)中文版

反面

Bluetooth Gamepad with Touch pad
Item Code: PG-9069

Applicable instructions:

1. Thanks for purchasing iPega developed Bluetooth Gamepad with Touch pad.
2. This Gamepad support playing games on Bluetooth enabled Android tablet / smart phone / TV box / smart TV / VR, IOS mobile phone / tablet，Win7 / Win8 / Win10 PC without any drivers.
3. The bottom of A/B/X/Y function key has white LED light. While the device is switched on, the LED illuminate four 3 sectrbs and its better for game playing in dark area.
4. L2 and R2 function keys are installed within the hall effect sensor. Make game playing be more accurately controlled.
5. Ergonomic design bring you extremely cool and comfortable hand hold feelings.
6. With dual motor vibration Function.There is vibration feedback while power on gamepad. Support playing games wich has vibration function: (under wired connected PC in X-INPUT mode only).
7. With Mouse touch fulcfion, operate more conveniently under Android PC platform.

※ Due to the official game platform software upgrades or source code changes and other not resist factors caused some of the game can not be played or connected with our Gamepad, iPega store tw Msrco rw:mop.whkibiy.iPega reserve the right of final interpretation for this.

Introduction for key functions:

Mouse touching pad function

Support mouse touch function,can operate more conveniently under Android/ PC platform.
1.Please move your finguns slightly on the sensitive area if you want to move the cursor.
2.Please click the touching pad once slightly if you want to select an object.
3.If you want to double click an object, please focus the cursor on the object and double click.

How to assemble phone holder on the gamepad

1.Align the three positioning slots of the gamepad with the three buttons on the top, and make the fixed clip across the bottom of the gamepad.
2.Align the positioning hole on the top of fixed clip with the toggle switch of the gamepad and push it up at the same time.
3.Assembling finished after confirmed the top of the clip fixed the edge of the gamepad.

How to detach the phone holder

1. Pull off the top edge of the fixed clip, then pull down until the edge is removed from the gamepad.
2. Move the fixed clip down and push it back at the same time.
3. Move the whole of fixed clip back, then the detachment is finished.

Electrical Parameters：

1.Working voltage：DC3.7V
2.Working current：50 mA
3.Continuous gameplay time: 10H
4.Static current: <35uA
5.Charging voltage/current：DC5V/500mA
6.Battery type：Li-polymer
7.Battery capacity：380mAh
8.Standby time：up to 60days once fully charged

Charge/ Sleep/ Wake up function of Gamepad:

1.The side of LED indicator will lit on while charging and will turn off after fully charged.
2.Sleep/Wake up function: Gamepad will enter into sleeping mode if not in use for 5 minute, and press HOME button for wake up and reconnect automatically.
3.The side of LED indicator flashing quickly for low battery remind.

Operation instructions:

	HID Mode(GamePad)	Keyboard/Mouse Mode
Bluetooth pairing buttons	**Press HOME button for 5 seconds**	**Press HOME button for 5 seconds**
Mode Switch location		
Remark		

	iOS system	Windows system
	iCade Mode	HID Mode (GamePad)
Bluetooth pairing buttons	**Press HOME button for 5 seconds**	**Press HOME button for 5 seconds**
Mode Switch location		
Remark	**Default English keyboard input**	Need buy a USB Bluetooth 3.0 receiver

Android Game Center

Scan to download Android Game Center
Android system users only

Usage of Android device

It supports the vast majority of games, such as: Shadow gun/Modern Warfare 5/Asphalt/Contract/metal Slug, and emulator games (such as MC4, Wild blood, Dungeon Hunter, Zombie, FC emulator, GBA emulator, arcade emulator, SFC emulator, N64 emulator, Shadow gun,sonic CD, Cory, Soul craft, zenonia4, 9 Innings 2013,Riptide GP, etc.). Or you can scan QR code to download Android Game Center and download games from Android Game Center for playing.
1.Pull the mode switch to 📱 position.
2.Press and hold HOME 5 seconds for first connection, release Home button until LED indicator under X/B/A/Y flash slowly turn to quickly.Pic1
3.Turn on Bluetooth function on Android system device, and click scan to search;
4.Find and select "PG-9069" for Bluetooth pairing; Pic2
5.The LED under X/B/A/Y key will be on after Bluetooth connected successfully; Pic3 (Press and hold Home 1 second for next connection)
6.You can scan QR code to download Android Game Center and download games from Android Game Center for playing.
7.Support kinds of games which download from Google Play Store, such as: Implosion / Dead Trigger / Dead Effect / CS Portable / The dungeon hunter 4 glory palace / SHADOWGUN: DeadZone / SoulCraft - Action RPG
Press and hold HOME 5 seconds for first connection

Usage of iOS devices

Support iOS non jail-breaking devices. Could play games which download from Apple APP Store. Searching "iCade" from APP Store will come out vast of iCade games for playing.
(Support parts of games under iCade mode as game devices is limited for iOS system.)
1.Firstly, you need to set keyboard input in English. Pic1
2.Pull the mode switch to 📱 position;
3.Press and hold HOME 5 seconds for first connection, release Home button until LED indicator under X/B/A/Y flash slowly turn to quickly; Pic2
4.Turn on Bluetooth function on iOS device, and click scan to search;
5.Find and select "PG-9069" for Bluetooth pairing; Pic3
6.The LED indicator under X/B/A/Y key will be on after Bluetooth connected successfully; Pic4 (Press and hold Home 1 second for reconnection)
Press and hold HOME 5 seconds for first connection

Support parts of games under iCade mode:

Akane the Kunoichi Lite-naruneko
Temple Run-Imangi Studios，LLC
Rush city-Acceleroto
Iron Frost-YOWPL, Inc.
Recess Riot-Deceased Pixel LLC
Super Mega Worm Lite - Deceased Pixel LLC
Emerald Mine - Les Bird
Guns n'Bottles - Ivanovich Games
Danmaku Unlimited 2 lite - Bullet Hell Shump
qub - Andrew Brinkhaus
Alien Annihilation-Free retro - space shooter
Heli Apps

Bullet Hell Infinite - Nicolas Bevillard
Retro Dust-Classic Arcade - Asteroids Vs Invaders
R Productions
J-Werewolf LTE - Daniel Novais
Recess Riot Lite - Deceased Pixel LLC
Space Inversion FREE - merlyn lear
Vector Star Brawl - Jorge Arroyo
The Invaders - RI Productions
Towerman - Tomek Szczepanski
Bunny Leap - John Carlyle

How to connect PC device for playing games by using USB data cable:

1.USB data cable is required to connect the USB port of the PC device with the gamepad. When the WIN7 or above system is connected by default, the indicator light is on, and showing the operation mode of X-XINPUT.
In X-INPUT wired mode, it can support the operation of vast majority of classic large-scale games in PC version.
Such as: 1.Need for Speed

How to connect PC device with Bluetooth:

1. Turn on Gamepad for Bluetooth pairing: Pull the mode switch to 📱 position. Press and hold HOME 5 seconds for first connection, release Home button until LED indicator under X/B/A/Y flash slowly turn to quickly.
2. Bluetooth pairing: Turn on the Bluetooth setting on our PC and start searching Bluetooth device. Detail operation as following:
2.1 Insert Bluetooth 3.0 receiver into the USB interface on PC device; Windows system will automatically install the driver.
2.2 After the driver is installed successfully, the symbol of the Bluetooth device will be displayed in the lower right corner of the computer.
2.3 Move the mouse to the Bluetooth symbol, click the right mouse button and select "Add Device";
2.4 After selecting "Add Device", the icon of the model of the device (PG-9069) will be searched in dialog box;
2.5 Click "Next" and select "Do not use the code to match", it will be automatically added after confirming, then remind the Bluetooth is connected successfully! After connecting OK, the indicator light is always on (Press and hold Home 1 second for reconnection)
2.6 It will set D_INPUT mode after the Bluetooth is connected successfully, and can support the games running in simulator way.

Instruction of Macro button:

Function Description	Through the Macro button, for example, we can set the function of A/B/X/Y button to R1 button and set D-pad function to L1 button. Then press R1 button will have the accurate attack function of A/B/X/Y buttons at the same time, press the L1 button will have the accelerate attack function of all D-pad buttons at the same time. Which will make you easy to defeat the game opponent.
Setting condition	1. Under Android Gamepad Mode 2. Suitable set Marco buttons in the Fighting games 3. The programmable button has L1,R1,L2,R2,A,B,X,Y,D-PAD（L1/R1/L2/R2 are main key，A/B/X/Y and D-PAD buttons are set key） 4. The back light under A/B/X/Y button is the indicator.

Follow below steps clear the Macro function:

Step 1	Click Macro button, indicator blink 2 times.
Step 2	Click one of the main key, such as R1 button, indicator blink 1 time.
Step 3	Choose and click the set key, such as A/B/X/Y buttons, the indicator blink 2 times while you click each set key.
Step 4	Click Macro button,indicator blink 4times means successful set R1 as a main key. While you press the R1 button at this time, it will have all A/B/X/Y buttons function at the same time. But R1 default key value is not existed until you clear the Marco function

Follow below steps clear the Macro function

Step 1	Click Macro button, indicator blink 2 times.
Step 2	Click R1 button, indicator blink 1 time.
Step 3	Click Macro button, indicator blink 4times means R1 button has cleared the Macro function and R1 key restores the default key value.
Remark	1. Set other Marco functional keys same as above steps. 2. It not support to store the Marco settings while game controller powered off. 3. Maximum 8 keys could be set in one time.

Instruction of Turbo button:

Function Description	A/B/X/Y,L1/R1,L1/R1,L2/R2 can be set as Turbo functions. Press the Turbo set button, it has the continuous attack function in the games.
Setting condition	1. Under Android Gamepad Mode. 2. Suitable set Turbo buttons in the Fighting games 3. Only A/B/X/Y,L1/R1/L2/R2 can be set as Turbo functions 4. The back light under A/B/X/Y button is the indicator.

Follow below steps set and clear the Turbo function:

Step 1	Press and hold the button you want set Turbo function (such as A button), then press the Turbo button until indicator blink,then release two buttons.
Step 2	Press and hold button A and the indicator blink all the time means A button was successful set Turbo function in the games.
Step 3	Clear Turbo function: Press and hold A button, then press Turbo button, indicator blink until you release two buttons, means you have cleared the Turbo function on A button and restores the default key value.
Remark	1. Follow above steps set other button B/X/Y/L1/R1/L2/R2 with Turbo functions. 2. It not support to store the Marco settings while game controller powered off.

Instruction of L2/R2 analog limit switch Function

In order to gain better gameplay experience during playing different games, you can set and playing gameplay control function for L2/ R2 buttons.
1. After turned on the analog limit switch function, the valid value of analog (0~100) will be between 60~70
2. After turned off the analog limit switch function, the valid value of analog (0~100) will be between 0~100

Notes：

1. Please do not store this product in wet or high-temperature areas.
2. Don't knap, beat, drub, pierce, or try to decompose this product, to avoid unnecessary damage to the product.
3. The product has built-in batteries, and please don't discard them together with the garbages.
4. Don't charge the controller in a place near the fire or other heat source.
5. Non professional personnel should not disassemble the product, otherwise it will not be covered in the after-sales warranty service.

Accessories List

Gamepad x1   Smart Phone Stand x1   User Manual x1   Micro USB Charging Cable x1

iPega and ePega trademarks all belong to PEGA LIMITED.
Patent NO．:ZL201630192784.2