




PS mini console game controller (PG-9122)English

Application instructions

1. Thanks for purchasing iPega PG-9122 PS mini console game controller;
2. This gamepad mainly use to connect PS mini game console for playing games;
3. Applicable device: PS mini game console.

★ Due to the official game platform software upgrades or source code changes and other not resisit factors caused some of the games can not be played or connected with our product, iPega have no responsibility. iPega reserve the right of final interpretation for this.

Function keys graphical representation



Electrical Parameters:

- 1.Working Voltage: DV3.7V;
- 2.Working Current: <30 mA;
- 3.Continus gameplay time: 20H;
- 4.Charging Voltage/ Current: DC5V/ ≤500mA
- 5.Communication mode: 2.4G, Transmission distance: ≤8M;
- 6.Battery capacity: 400mAh.


Accessories List




Gamepad x1



Receiver x1



User Manual x1



Micro USB cable x 1

Instructions:

1. Basic usage:

- A.Insert the wireless receiver into the interface of the console and power on the console;
- B.Press POWER button power on the gamepad and it will connected with the receiver automatically, all button define is same with original gamepad.
- C.Once successfully connected, you can playing games.
- D.Long press POWER button to trun off the gamepad.
- E.If it can't be connected or the gamepad was stucked or there is no response during usage, please press the reset key by a clip, then press power to connect.

2. TURBO function and usage

- A.Turbo usage: Press a key (A,B,X,Y,L,R) first, then press turbo key, the key will be defined as continue press. For example, set the bullet key when playing arcade simulator like that, then you can bursts when you press and hold the key.
- B.Clear Turbo function: Press a key (A,B,X,Y,L,R) first, then press turbo,it will clear the set turbo function.

3. AUTO Key Function and Usage:

- A: AUTO usage: Press a key (A,B,X,Y,L,R) first, then press Auto key,the key will be defined as continue press automatically. For example,set the bullet key when playing arcade simulator like that, then it will bursts automatically, there is no need press the key.
- B. Clear AUTO function: Press a key (A,B,X,Y,L,R) first, then press AUTO,it will clear the function of automatically continue press.

4. Instruction of LED indicator light.

- A: The left LED is the first indicator light which is red, the LED on the right is the second indicator light which is green.
- B: The Function of the first LED are as below:
Indicate searching and pairing while powered on and the LED flash quickly, it will turn on after paired; The LED blink rapidly to remind low battery, LED blink slowly while recharging it, LED turn on while fully charged. LED blink slowly while recharge at gamepad turned off mode and LED will turn off while fully charged.
- C: The function of the second LED indicator light as below:
LED blink and turn off when power on the gameapd,the LED is regard as TURBO/AUTO indicator, it will keeps on while setting Turbo keys. The LED flash quickly when setting the Turbo key, it keep on while release the button. LED keep blink rapidly when setting AUTO key.

Charge/ Sleep/ Wake up function of Gamepad

- 1.The gamepad connected with the receiver during application. Gamepad will enter sleep mode within 5 minutes if not be used.
- 2.Press the Power button to connect automatically for operate again.
- 3.If it can't be connected or the gamepad is stucked or there is no response during usage, please press the reset key by a clip, then press power to connect.
- 4.Gamepad will auto power-off within 30 seconds if it not be connected. If you wanna operate, press Power button power on.

Notes:

1. Please do not store this product in wet or high-temperature areas.
2. Don't knap, beat, drub, pierce, or try to decompose this product, to avoid unnecessary damage to the product.
3. The product has built-in batteries, and please don't discard them together with the garbages.
4. Don't charge the controller in a place near the fire or other heat source.
5. Non professional personnel should not disassemble the product, otherwise it will not be covered in the after-sales warranty service.