



派鲨鱼


数显充电电池包

产品说明书 (PG-XBX016)

产品特征:

- 1.本产品适用于XBX/XBS原装手柄;
- 2.配备LED显示屏,实时显示电池电量及充电状态;
- 3.内置大容量可充电电池,持久续航,安全可靠;
- 4.即插即用,操作简单;

产品图示:




产品特性参数:


输入电压: DC5V
输入电流: ≤300mA
充电时间: 3-4小时
续航时间: 约20小时
单个电池容量: 1400mAh

产品使用说明:

1. 将电池装入XBX/XBS原装手柄,并确保装配到位后,即可使用。使用过程中,按一下电量开关LED显示屏将显示电池当前可用电量同时LOGO灯点亮,30秒后自动熄灭。



- 2.给电池包充电:用附带的USB充电线,一端插入电池顶部的Type-C端口另一端连接至XBX/XBS主机的USB端口,连接成功后,LED显示屏将闪烁并显示电池当前电量同时LOGO灯点亮,当电池充满后,电量将显示为100,拔掉充电线显示屏熄灭;




注意事项:

- 1.主机无法正确显示第三方电池电量,请以电池数显电量为准。
- 2.如长期未使用,每三个月需给电池包充一次电;如超过六个月未使用,也未给电池包充电有可能造成电池深度自放电而无法再正常充电使用;
- 3.不可拆解或短路电池包输出端,以免造成不可逆永久损坏。
- 4.请不要把本产品在潮湿或高温地方存储。

- 5.不要敲击、摔打、刺穿、或试图去分解本产品,以免对产品造成不必要的损害。
- 6.非专业人员误拆卸本产品,否则不在售后保修服务内。
- 7.产品内有电芯和电容等电子材料,不可随便丢弃,须集中给有资质的回收机构。
- 8.因不可抗拒的因素造成部分产品无法连接操作,我公司不负任何责任,对此我公司保留最终解释权;

产品清单:



充电电池包 x1

说明书 x1

USB充电线 x1



派鲨鱼


Battery Pack With LED Display

User Manual (PG-XBX016)

Product Description:

1. This product is compatible with the original XBX/XBS controller.
2. Equipped with an LED display, it shows real-time battery level and charging status.
3. Built-in large capacity rechargeable battery for long-lasting operation and safety.
4. Plug and play, easy to operate.

Function Keys:




Specifications:


Input Voltage : DC 5V
Input Current: ≤300mA
Charging hours : 3 - 4 hours
Battery life: ~20 hours
Battery Capacity: 1400mAh

Product instructions:

1. Install the battery to the XBX/XBS original controller. Once assembled, you can start using it. Simply press the power button on the LED display to see the current available battery level. The LED display will automatically turn off after 30 seconds.



2. To charge the battery pack, use the provided USB charging cable. Insert one end into the Type-C port on the top of the battery pack, and connect the other end to the USB port on the XBX/XBS console. Once successfully connected, the LED display will blink and show the current battery level. When the battery is fully charged, the display will show 100%. After charging, simply unplug the charging cable, and the display will turn off.




Note:

1. The main unit may not accurately display the battery level of third-party batteries. Please rely on the battery pack's digital display for accurate information.
2. If the battery pack is not used for an extended period, it should be charged every three months. If it goes unused for more than six months without charging, it may experience deep self-discharge and may not be able to charge properly.

3. Do not disassemble or short-circuit the output end of the battery pack to avoid irreversible damage.
4. Please do not store this product in damp or high-temperature areas.
5. Avoid hitting, dropping, piercing, or attempting to disassemble the product to prevent unnecessary damage.
6. Non-professionals should not disassemble the product, as it will void the warranty.
7. The product contains electronic components such as batteries and capacitors and should not be disposed of casually. Please dispose of them properly by giving them to qualified recycling facilities.
8. If certain products cannot connect or operate due to uncontrollable factors, our company does not assume any responsibility. We reserve the right to provide the final interpretation in such cases.

Product List:



Battery pack x 1

Manual x 1

USB cable x 1